

Overview

This kit contains 30 pounds of tumbled stone used to adorn the firebox of the models listed below. Because this kit includes more than enough stones for nearly every unit, we recommend extra stones be kept for future use.

Compatibility

- 616 Diamond-Fyre Insert
- 3615, 4415, 4415 ST, and 6015 Fireplaces
- ProBuilder 42
- DaVinci Fireplace

Packing List

- 20 Pounds of Large Stones
- 10 Pounds of Small Stones

Amount To Use (see pictures below and on the next page)

We recommend using approximately 2 to 3 pounds for every linear foot of firebox for naturally drafted appliances. DaVinci fireplaces may use 2 to 4 pounds per linear foot. Quantity will vary based upon fireplace type (see-through, pier, etc.) and the aesthetic preference of the consumer. Guidelines are below:

- 6015 – Use 10 to 15 pounds total
- 4415 – Use 7.5 to 11 pounds total
- 3615 – Use 6 to 9 pounds total
- 616 Diamond-Fyre Insert – Use 5 to 7.5 pounds total
- DaVinci Fireplace – Use 2 to 4 pounds per linear foot (see-through, pier, or island may use more).
- ProBuilder 42 – Use 7.5 to 11 pounds total

Placing the Media

Place the media in a random manner on top of the crushed glass media.

- DO NOT PLACE MEDIA OVER BURNER PORTS (THIS WILL CAUSE SOOTING).
- DO NOT STACK MEDIA IN PILES THAT MAY FALL OVER OR BLOCK AIRFLOW.
- IF YOU LIVE IN A GLASS HOUSE, DO NOT THROW THESE STONES.

EXAMPLE: 6015 Fireplace



Media Set – Tumbled Stone Installation Instructions (SKU 94500961)



EXAMPLE: DaVinci Fireplace

